



KEVIN'S CONNECTIONS, LLC

Cell: (970)618-7437, Hm: (970) 963-1036, Fax: (970) 963-9802, 0196 Rabbit Rd., Carbondale, Co. 81623

Living Room Instruction Sheet

The Comcast remote control is very versatile, capable of controlling the cable box, VCR, and TV. These instructions will describe the basic functions needed for the use of your A/V equipment.

The first step for watching TV, or VCR is always the same:

TURN ON THE TV by first pressing the “TV” button, then pressing the “POWER” button.

This puts the remote control in the “TV Mode”. In other words, the remote control is now controlling the TV (not the cable box).

To watch TV : Complete the steps as described above.

Now, press the “**INPUT**” button (located at the bottom left of the 10-key pad), until you see the input screen on the TV highlighting the words “**VIDEO-3/PC**”. You may have to press the Input button multiple times.

NEXT: Press the “**CABLE**” button at the top of the remote. Press the “**POWER**” button to turn on the cable box (if it’s not already on).

You should be seeing your cable picture now.

Use the Comcast remote to control the cable box in the usual way.

For **Cable Music** choose a channel between 900 and 946. Turn on the stereo system and select the **AUX** input.

To watch VCR: Turn on the TV as described above.

Now, press the “**INPUT**” button (located at the bottom left of the 10-key pad), until you see the input screen on the TV highlighting the words “**VIDEO-1**”. You may have to press the Input button multiple times.

NEXT: Press the “**AUX**” button at the top of the remote. Press the “**POWER**” button to turn on the VCR.

This puts the remote control in the “VCR”. The remote will now control the basic VCR transport functions.

Note: You may wish to use the Mitsubishi VCR’s remote for more than control.

The cable box signal comes thru the VCR’s “L1” input. If you want to record just press the record button.

To turn things off press the red “ALL ON” button.

You may leave the cable box on all the time.

This POWER button turns On or Off the device selected with the Input buttons.

